



START THE CAMPER DOOR AT 43" FROM THE INSIDE OF THE RISER WALL

START REFER VENT FRAMING OF 20" W X 36" TALL AT 19" B.F.D. BOTTOM OF VENT START AT 2" A.F.F.

20 1/2"

19" CENTER THE KITCHEN WINDOW AT 20 1/2" FROM THE INSIDE OF THE RISER WALL AND 42" OFF THE FLOOR TO THE BOTTOM OF THE WINDOW.

CENTER THE DINETTE WINDOW AT 38 1/2" FROM THE INSIDE OF THE RISER WALL AND 34" OFF THE FLOOR TO THE BOTTOM OF THE WINDOW.

83 1/2"

62 15/16"