



START THE GAMPER DOOR AT 42" FROM THE INSIDE OF THE RISER WALL.

CENTER THE DINETTE WINDOW AT 37" FROM THE INSIDE OF THE RISER WALL AND 34" OFF THE FLOOR TO THE BOTTOM OF THE WINDOW.